SLIPLINING

Metal Culvert Overview Flowchart
Structural Defects Flowchart (Metal)
Bedding Deficiencies Flowchart (Metal)
Hydraulic Capacity Flowchart (Metal)

1. OVERVIEW

Sliplining is a method of rehabilitation in which a new pipe of smaller diameter is inserted directly into the deteriorated culvert by pulling or pushing. Any pipe type used to construct new culverts can also be used for sliplining (Ballinger and Drake, 1995). With this method, the annular space between the host pipe and the newly installed pipe is created, which is typically grouted with a cementitious material.

The method can be categorized into:

- ***Segmental sliplining*** – A liner is being assembled from short pipe segments at the entry point into the existing pipe, from where the liner is being pulled/pushed into the pipe for the length of each added segment.
- ***Continuous sliplining*** - A liner is manufactured as a continuous pipe or assembled in the field prior to insertion (e.g. by fusing HDPE pipes) to match the entire length of the existing pipe.



Figure 1. Segmental sliplining (ASTM F 585).



Figure 2. Continuous sliplining (Iseley and Najafi, 1995)

2. LINER MATERIALS

A variety of pipe types can be used for sliplining, e.g. reinforced concrete pipe (RCP), plastic pipes (HDPE or PVC, corrugated on the outer surface of the pipe, corrugated on the outside and inside surfaces, or with both surfaces smooth), corrugated metal pipe, and centrifugally cast glass-fiber-reinforced polymer mortar (CCFRPM) pipes (Ballinger and Drake, 1995).

Corrugated metal pipe, pipe arches and structural plate products are available in many sizes for sliplining culvert pipes. In addition, concrete-lined corrugated metal pipes (CLCMP) can be used, for which the concrete lining is plant-applied (Rinker Materials, 1992).

Johnson and Zollars (1992) investigated three different types of PE pipe for sliplining: smooth PE with mechanical joints, smooth PE with fused joints, and corrugated PE pipe. Newton (1999) discussed the practicality of continuous sliplining of failing culverts with polyethylene (PE) pipe showing that some of the major railroads installed this type of liner in the 1990s with very positive results, and described a coupling system for jointing HDPE pipes by “screwing together” bell-and-spigot ends.

CCFRPM pipes are available in a range of sizes from 18 in. to 110 in. in diameter, and standard pipe lengths of 20 ft. Standard stiffness classes (minimum pipe stiffness in psi) used for sliplining are SN 36 and SN 46 (Hobas Pipe USA, 2008).

One patented system uses stainless steel sleeves for continuous sliplining of culverts (LINK-PIPE, 2008c).

3. METHOD APPLICABILITY

Circular pipes in a wide range of diameters can be rehabilitated with sliplining, i.e., pipes with ID 4 in. to 63 in. can be repaired with continuous sliplining, and 4 in. to 152 in. pipes with segmental sliplining. Custom shapes are possible with segmental sliplining. Diameter changes may prevent this method. Length is not a limitation, as pipelines over 5,000 ft have been sliplined.

The method is typically limited to straight pipe alignment. However, continuous sliplining can accommodate large radius bends.

The method can be applied in any culvert pipe material and shape. Corrugations on the inside surface do not hinder use of this method. Pipe condition is generally not a limitation, e.g., the pipe can be corroded, deformed, and near collapse.

Sliplining can be performed in live flow conditions and flow bypass is seldom required (Thornton et al, 2005).

4. CONSTRUCTION ISSUES

4.1. INSTALLATION PROCEDURE

The following are steps that are normally required for the sliplining process (modified from Thornton et al., 2005, and Ballinger and Drake, 1995):

- Inspect the culvert (diameter changes along the culvert barrel, connecting pipes, protrusions, roots, sediment)
- Determine diameter of sliplining pipe and material
- Clean and clear the culvert, if required
- Divert and/or control water passing through the culvert (setup flow bypass), if required
- Make excavations if required
- Make any repairs in the existing culvert structure that may be necessary prior to sliplining. Repair embankment as well by identifying voids and grouting behind the culvert.
- Construct a guide way on the invert of the culvert, if required to facilitate the sliplining of sections into the existing culvert.
- Install pipe segments or continuous liner into the host culvert pipe
- Upon completion, a 24-hours relaxation period is recommended
- Inspect the installed slipliner pipe (CCTV or man-entry visual inspection)
- Perform leakage or other testing, as required
- Reconnect and stabilize terminal connections. Grout the annular space.
- Restore flow (remove bypass pumping) if applicable, and perform the site cleanup.
- As necessary, complete the project by constructing or modifying head- and wing-walls on the ends of the culvert.

If corrugated pipes or pipe arch sections are used for sliplining of corrugated culverts, either timber skids or a concrete “sidewalk” should be installed in the invert so that the liner may be slid into position. They may not be needed if the culvert is less than 150 ft long and the culvert is 36 in. or less in diameter (Ballinger and Drake, 1995).

When sliplining long culverts or if the insertion is expected to be difficult (e.g., there are offset joints or other irregularities in the existing culvert), conically shaped mechanical pulling heads can be used that enable easier gliding of the liner inside the culvert (Figure 3). For HDPE liners, a less sophisticated but cost-effective approach is to fabricate a pulling head out of a few extra feet of liner (Figure 4). The leading edge of the HDPE liner has evenly spaced wedges cut out, and the remaining ends are collapsed towards the center and fastened together with bolts, threaded rods or metal straps and attached to a cable (Kanters, 2007).

Figure 3. Conically shaped pulling head for sliplining (Kanters, 2007)

Figure 4. Pulling head for sliplining field-fabricated out of the HDPE pipe (Kanters, 2007)

CSPI (2004) outlined steps in relining procedure using corrugated steel pipe and corrugated steel pipe arch.

4.1.1. Assembling Continuous Liners

Each slipliner product has its own joint design. Heat fusion is a method for joining sections of smooth wall and some corrugated HDPE pipes. After aligning the two ends (Figure 5), pipe sections are connected by welding (Figure 6).

Figure 5. Aligning two pipe sections before welding (D. A. Van Dam, 2008)

Figure 6. Welding HDPE liner sections from inside the pipe (D. A. Van Dam, 2008)

Some HDPE products have integral threads that allow sections to be easily joined without special equipment. A coupling system for joining HDPE pipes by “screwing together” bell-and-spigot is shown in Figure 7. Some HDPE pipes come with a (patented) “snap” joining system (Figure 8) in which two sections of solid wall HDPE pipe, ranging in length from 2 ft to 50 ft and having male and female ends, are aligned and “snapped” together using chains and pressure from the excavator (Snap-Tite, 2008).

Figure 7. Thread-Loc joint for joining HDPE pipes (KWH Pipe, 2008b)

Figure 8. Male end of pipe (left) and a connected joint completed by snapping (right) (ISCO Industries, 2005)

Other types of pipe typically use gasketed or glued bell-and-spigot joints, or a restrained joint mechanism (Figure 9). Figure 10 and Figure 11 show how stainless steel sleeves are assembled into a continuous liner.

Figure 9. "Ring-and-pin" gasketed joint (Potter, 2009).

Figure 10. On-site assembly of continuous liner from stainless steel sleeves (LINK-PIPE, 2008c).



Figure 11. Connecting stainless sleeves into a continuous liner (LINK-PIPE, 2008c).

4.1.2. Insertion of Slipliner

Duncan (1984) described insertion of a slipliner made from corrugated structural plate arch in one case study where a 240 ft length of failing pipe arch culvert (structural steel plate with span of 14 ft and rise of 9 ft 8 in.) was sliplined with corrugated structural plate arch (10-gauge, span of 11 ft 10 in., rise of 7 ft 3 in). A guide was constructed to help assemble the slipliner pipe from plates and roll it in place. The guide was made from a 1.5 ft × 8 ft channel iron, set to grade every 10 ft and anchored to the culvert every 3.5 ft (Figure 12). A pit in front of the cut-off wall enabled a protective coating (asbestos-bonded asphalt coating) to be manually applied underneath the pipe (Figure 13). The pipe was assembled by bolting together bottom plates first to create the bottom half, and then bolting to it three top plates already assembled on the ground. Rollers were bolted to the pipe every 12 ft (Figure 14). Brackets were installed in the culvert's pipe bottom and the walls, and the slipliner pipe was pulled through the culvert.



Figure 12. Guide for rolling (Duncan, 1984)



Figure 13. Assembly area and channel guide in place (Duncan, 1984)



Figure 14. Roller system (Duncan, 1984)

4.1.3. Grouting of Annular Space

In sliplining installations, grouting the annulus between the liner and host pipe provides support to the liner pipe that comes from the host pipe that has settled well in the soil. Grouting can increase the structural differential-pressure capability of the polyethylene pipe by up to four-fold. (Phillips Driscopipe Inc, 2002.).

Jenkins and Kroll (1981) studied soil and cement encapsulation of PE pipe to determine the benefit derived in buckling resistance. They showed that cement grout can improve capability of the pipe by a factor of five. Buckling resistance of pipe contained by compacted soil was found 2-3 times greater than that of free standing pipe resistance. They also pointed out that when the annual space is not completely filled with grout, even if the liner pipe cannot generally deform even under much larger loads, the local distortion of the pipe still occurs at the loading point. For that reason, the grout support must be complete, i.e., at least 80% of the circumference must be grouted in order to achieve a higher buckling resistance. When undesirable point loads are avoided in a grouted pipe, the grout in the annulus protects the liner pipe and thus enhances the durability of the pipe.

Zhao et al. (2003) presented the effect of the grout on the performance of slipline pipe based on a three-year study on the performance of a sliplined water main in the City of Ottawa, Canada (Table 1). They

also stated that the decision on annular space grouting is mainly based on its impact on construction and cost. Grouting the annulus also minimizes the buckling potential due to water accumulation in the annulus and freeze-up when the pipe is installed within the frost susceptible depth in cold regions.

Table 1: Pros and cons of grouting the annular space in sliplining (modified after Zhao et al, 2003)

Advantages of using the grout	Disadvantages of using the grout
▪ Increases the buckling resistance of the liner pipe	▪ Increased construction cost and longer installation time
▪ Increases the load carrying capacity	▪ Potential collapse of liner pipe during grout injection
▪ Can be used to control load-sharing between liner and host pipe	▪ Requirement for blocking of all openings that may allow grout to escape during pouring
▪ Eliminates sharp loading edges on the liner pipe from failed host pipe	▪ Requirement for a proper grout injection procedure
▪ Reduces longitudinal movements due to differential temperatures, thus minimizing shear-off potentials at lateral connections	
▪ Increases the service life	

Duncan (1984) provided recommendations on how to position the holes for grouting the annular space: at 3 and 9 o'clock positions at 8 ft intervals along the sliplining pipe, and at 11 and 1 o'clock positions at 4 ft intervals. Also, to facilitate filling under the bottom of the arch culvert, grout holes should be at 5 and 7 o'clock positions at 4 ft intervals.

Grouting of the annular space between the pipes must be continuous with no voids (a few small voids can be tolerated) to achieve the improved structural support that is needed. The Phillips DriscoPipe (1991) design manual showed the importance of complete grouting for sliplining with plastic pipe. The maximum external pressure differential on unsupported liner will increase when the gap between liner and original culvert is eliminated. For example, based on liner design theory at that time, Phillips DriscoPipe (1991) indicated that service life of ungrouted HDPE SDR 26 pipe is 50 years for 9 ft of water head. However, when the same pipe is properly grouted into an existing pipe, it can withstand 36 ft of external groundwater.

Stephens (1996) provided useful guidelines for grouting the annular space of sliplined pipe (test shown was modified by authors):

- The grout design should specify mix design (proportions of constituents), density of slurry (cement, cement/flyash and water) and density of grout (after dispersant is added), viscosity, initial set time, 24-hour and 28-day compressive strengths, shrinkage, stability, and "bleed" (fluid loss).
- Initial set-up time is extremely important. The grout mix must remain fluid and not thicken for a period of at least two hours (see Figure 17). Grout should be tested in accordance with ASTM C939.
- Fly ash based lightweight grouts are not recommended for slipliner grouting if the grout would be exposed to excessive water infiltration before it sets.
- If the existing pipe has deflected from a straight alignment, there is the possibility that trapped air will result in discontinuous grout.
- Grout injection should start at the upstream end of the pipe and progress toward the downstream end so as to more easily displace water and debris. Suitable injection tubes must be inserted at the upstream end (e.g, as shown in Figure 15). Vent pipes installed at the downstream end should be 150% larger than injection tubes to minimize the potential for clogging.
- In the field, every batch of grout should be tested for density and viscosity.
- Any suspected voids in the soil must be pressure grouted prior to inserting the slipliner.
- Maximum grout injection pressure must not exceed the slipliner manufacturer's recommendations.

For evaluating the proposed grout mix, the following need to be considered (Stephens, 1996): (1) condition of the pipe wall beneath the corroded layer, (2) groundwater infiltration; (3) porosity of the

corroded portion of pipe (for fluid loss considerations, see Figure 16), (4) the length of runs, type of pipe to be used, OD of slipliner pipe, pipe stiffness, maximum injection pressure allowed, weight of pipe filled with water (if flotation or misalignment are not allowed), and (5) the joint deflection limit of the slipliner pipe if flotation is expected.

Figure 15. Grout tubes and slipliner pipe inside existing culvert (D. A. Van Dam, 2008)

Figure 16. A corroded pipe can cause thickening of the grout (Stephens, 1996)

Figure 17. A collapsed 18 in. welded steel pipe in a 36 in. steel casing attributed to too quick grout set-up time (Stephens, 1996)

4.2. OTHER ISSUES

4.2.1. Flammability of Polyethylene (PE) Slipliners

North Dakota DOT incurred severe damage to some polyethylene (PE) liners installed in culverts due to ditch fires. Katti et al. (2003) investigated options to address the flammability of these liners. The research reviewed several coatings that could be applied to the inside of PE liners, as well as CIP liners and centrifugally cast glass-fiber-reinforced polymer mortar **(**CCFRPM) pipes. The CCFRPM pipe was found to be the best solution, provided it was fitted with concrete end caps to ensure resistance to fire.

5. QA/QC CONSIDERATIONS

PPI (1995) prepared *Guidance and Recommendations on the Use of Polyethylene (PE) Pipe for the Sliplining of Sewers,* which describe the specifications, design considerations, and installation procedures for continuous sliplining utilizing polyethylene liners.

Goodwin et al. (1997) provided guidelines for writing specifications for successful sliplining.

Indiana DOT's standard specifications (INDOT, 2009) require a Quality Control Plan (QCP) to be submitted to the engineer for acceptance at least 15 days prior to the start of sliplining, which must include, as a minimum, identification of the QC representative by name and documentation verifying the QC representative's experience; the contractor's method for cleaning and preparation of the existing pipe; method for joining, welding, or fusing the pipe joints; the personnel who will be welding or fusing the liners and their certification; the method and frequency of destructive and non-destructive testing on the welded or fused joints; the initial testing of the first joint, weld or fusion at each liner installation location; the corrective action that will be taken if defective or non-passing joints are found; the grouting process including the daily calibration process procedures for the grout generating equipment; inspection of bulkheads; specific job mix of the grout concentrate; the grouting procedure to ensure complete filling of voids; the corrective action to be taken if the grout compressive strength does not meet specifications; and the corrective action if the installation of the grout causes damage or deflection to the liner.

As grouting work is typically sub-contacted and the quality of grouting contractors can vary considerably, Caltrans (2003) recommends a list of submittals and calculations that the grouting sub-contractor should be required to forward to the project engineer.

6. STANDARDS AND SPECIFICATIONS

ASTM D2657 describes the general procedures for making joints with polyolefin pipe and fittings by means of heat fusion joining techniques (material standard, continuous sliplining).

ASTM D3212 covers joints for plastic pipe systems intended for drain and gravity sewage pipe at internal or external pressure less than 25 ft head using flexible watertight elastomeric seals. Test requirements, test methods, and acceptable materials are specified (material standard, segmental sliplining).

ASTM D3262 covers machine-made glass-fiber-reinforced thermosetting-resin (fiberglass) pipes (Material standard).

ASTM D4161 covers axially unrestrained bell-and-spigot gasket joints including couplings required for machine-made "fiberglass" (glass-fiber-reinforced thermosetting-resin) pipe systems, 8 in. through 144 in. (material standard, segmental sliplining)

ASTM D6783 covers the testing and requirements for polymer concrete pipes. This specification is suited primarily for pipes to be installed by direct burial and pipe jacking but may be for sliplining as well (material standard, segmental sliplining).

ASTM F585 describes the design considerations, material selection considerations, and installation procedures for the rehabilitation of sanitary and storm sewers by the insertion of polyethylene pipe through the existing pipe, along the previously existing line and grade (installation standard).

ISO/TR 10465-1 describes the procedures for underground installation of flexible GRP pipes (Installation standard).

NASTT (2006f) outlined QA/QC issues for thermoset pipe (e.g., CCFRPM) that can be installed by sliplining. QA/QC should address the component products (the resin, the fillers and the reinforcing agents), the design (thickness, host pipe configuration, corrosion resistance, hoop strength and fit), and installation (joint fit, installation method, lateral restoration and grouting).

Additional standards and specifications associated with sliplining are listed in Thornton et al. (2005).

7. EXAMPLE CASE HISTORIES

7.1.1. Sliplining with RCP

A case study of segmental sliplining a twin barrel metal culvert with precast concrete pipe in Woodbridge, VA was illustrated in the appendix of FHWA's *Culvert Repair Practices Manual* (Ballinger and Drake, 1995). The host corrugated metal pipe (CMP) was a 96" vertical oval pipe. After concrete slab was cast to fill erosion holes under the invert and to establish the grade, the 66" concrete pipe sections were installed, and the annular space was grouted.

Vaillancourt (2002) described a case study of segmental sliplining with reinforced concrete pipe (RCP) for the Maine DOT, Jepson Brook Culvert Rehabilitation in Lewiston, ME. The existing corrugated metal culvert, which was 1,048-ft long and 144" in diameter, was relined with a 108" RCP structure. The RCP segments were installed by "pushing-in-place" the segments inside the CMP. A special cart was fabricated to drive the precast concrete segments inside the pipe. Jacks were used to lift the segments off the ground while the cart was pushed along the existing tunnel with a Bobcat loader. At the target location, the jacks were lowered and the pipe homed with the previously positioned pipe using two 6-ton come-alongs anchored in two holes that were later used for pumping grout between the old metal and new concrete pipes. The process was repeated for each pipe segment.

7.1.2. Sliplining with Metal Pipe

Duncan (1984) reported the use of corrugated structural plate arch for sliplining of corroded structural steel plate culvert by the MT/DOT. In a case study near Hardin, MT, the 260 ft long failing culvert with a cross-section of 14ft × 9ft-8in was sliplined.

7.1.3. Sliplining with HDPE

Selected culvert rehabilitation projects utilizing Weholite® Pipe have been summarized in case histories downloadable from the web (Table 2). Weholite® pipe is large diameter, lightweight HDPE pipe for gravity and low pressure applications, with smooth outer wall for easy insertion and smooth "non stick" inner surface. It is available in a wide range of sizes from 18" to 120" in diameter, and standard pipe lengths of 20 ft, 40 ft and 50 ft. The slipliner pipe is typically delivered to site in sections and after aligning the pieces are welded from the inside of pipe. After completed welding, the pipe is pushed into the existing culvert, and the annular space grouted (KWH Pipe: *Weholite®*)

Table 2. Culvert sliplining projects with Weholite pipe

Project	Year	Existing culvert			Slipliner pipe	Reference
South Indiana, I-64		CSP	96" ID	?	HDPE 72" OD	(KWH Pipe: *Case…)* case study #110
HWY 401, Canada		CMP	24" ID	300 ft	HDPE 21" OD	(KWH Pipe: *Case…*) case study #111
Falmouth, ME		CMP	90" ID	122 ft	HDPE 90" OD	(KWH Pipe: *Case…*) case study #117
Bancroft, Ontario	2006	CSP	77" ID	?	HDPE 59" OD	(KWH Pipe: *Case…*) case study #124
Veil, CO, I-70		CMP	?	235 ft	HDPE 66" OD	(KWH Pipe: *Case…*) case study #136
ODOT District 12, I-90		CMP	102" ID	835 ft	HDPE 72" OD	(D. A. Van Dam & Associates: *Large…)*
ODOT District 5, I-70		CMP	108" ID	322 ft	HDPE 84" OD	(D. A. Van Dam & Associates: *Large…)*
Crawford County, OH		CMP	108" ID	120 ft	HDPE 90" OD	(D. A. Van Dam & Associates: *Large…)*
Williams County, OH		CMP	54" ID	180 ft	HDPE 42" OD	(D. A. Van Dam & Associates: *Large…)*
Summit County, OH		CMP	102" ID	123 ft	HDPE 90" OD	(D. A. Van Dam & Associates: *Large…)*
ODOT District 7, OH		2 CMP		325 ft	HDPE 54" OD	(D. A. Van Dam & Associates: *Large…)*
ODOT District 10, OH		CMP	96" ID	143 ft	HDPE 72" OD	(D. A. Van Dam & Associates: *Large…)*
Cuyahoga County, OH		CMP	120" ID	190 ft	HDPE 96" OD	(KWH Pipe: *Case…*) case study #126; (D.A. Van Dam 2005)
ODOT District 10, Columbus, OH, I-270	2006	CMP	156" ID	440 ft	HDPE 119" OD	(D.A. Van Dam 2006)

Several culvert rehabilitation projects utilizing Snap-Tite® Culvert Lining System have been summarized in field reports downloadable from the internet (Table 3). Examples of sliplined culverts are shown in Figure 18 and Figure 19.

Figure 18. Snap-Tite® inside the CMP culvert (ISCO Industries 2005)

Figure 19. Snap-Tite® inside the concrete box culvert (ISCO Industries 2005)

Table 3. Culvert sliplining projects with Snap-Tite pipe

Location	Year	Existing culvert			Slipliner pipe	Reference
Bartow, WV	2002	CMP	30" ID	116 ft	HDPE 20" OD	(Snap-Tite: *Culvert…*)
Marion County, OR	2001	CMP	30" ID	110 ft	HDPE 28" OD	(Pech, 2001)
Monmouth, NJ	2001	CMP	54" ID	475 ft	HDPE 48" OD	(Snap-Tite: *Culvert…*)

Ruth Lake, CA	2000	CMP	72” ID	190 ft	HDPE 63” OD	(Snap-Tite: *Culvert…*)
Weston, WV	2008	CMP	66” ID	156 ft	HDPE 54” OD	(Snap-Tite: *Culvert…*)

Pech (2001) described another sliplining case study in Marion County, OR. A 30” CMP culvert, 110 ft long and 20 ft below the road surface, was sliplined with a 28” Snap-Tite pipe. The liner was installed in 20 ft segments. The push was rather difficult but successfully completed. The culvert had sag and having the liner with a degree of flexibility proved advantageous. Smooth joint transitions reduced the possibility of debris getting caught and creating obstructions. The annular space was rather small and no grouting was done.

The FHWA completed a culvert rehabilitation project in Shenandoah National Park, VA in 1999 (ISCO Industries 2001). The project scope included sliplining of 56 CMP culverts with inside diameters ranging from 18” to 36”, with total length of 4,800 ft. The slipliner pipe was Snap-Tite®. The project was unusual because traversing the Appalachian Mountains required installing pipe on slopes as steep as 60°.

Oregon DOT (ORDOT) reported sliplining corrugated metal culverts with HDPE pipe. A 36” pipe and 200 ft long (Harbor Hole Culvert Rehab Project) was sliplined with 34” HDPE pipe and the annular space was subsequently grouted (John Woodroof, ORDOT, personal communication).

Two segmental sliplining were completed in Iowa in 1995. In Audubon County, IA, a 102 ft long 36" deteriorated corrugated metal culvert was sliplined with a 32" HDPE pipe. In Hamilton County, IA, a 339 ft long 42" culvert was sliplined with a 32" HDPE pipe. ("Plastic …" *Technology News*, Oct-Nov 1997)

North Dakota DOT (ND DOT) incurred severe damage to some polyethylene (PE) liners installed in corrugated metal culverts due to ditch fires. ***Cost Effective Non-Flammable Pipe Liners*** (Katti et al, 2003) investigated options to address the flammability of these liners. The research reviewed several coatings that could be applied to the inside of PE liners, CIP liners (manufactured by Inliner, Insituform, U-Liner) and Hobas pipe (CC-GRP). The Hobas pipe was found to be the best solution, however it has to be fitted with concrete end caps to ensure resistance to fire.

7.1.4. Sliplining with CCFRPM

Selected culvert rehabilitation projects utilizing centrifugally cast glass-fiber-reinforced polymer mortar (CCFRPM) pipes are summarized in Table 4. CCFRPM pipes are available in a range of sizes from 18 in. to 110 in. in diameter, and standard pipe lengths of 20 ft. Standard stiffness classes (minimum pipe stiffness in psi) used for sliplining are SN 36 and SN 46 (Rick Turkopp, Hobas Pipe USA, personal communication).

Table 4. Selected recent culvert sliplining projects utilizing CCFRPM pipe

Location	Year	Length	Slipliner pipe
Houston, TX	2007	60 ft	CCFRPM pipe ID 24 in.
Smyrna, GA	2007	417 ft	CCFRPM pipe ID 72 in.
Smyrna, GA	2007	1,143 ft	CCFRPM pipe ID 78 in.
Smyrna, GA	2007	39 ft	CCFRPM pipe ID 84 in.
Reading, PA	2006	80 ft	CCFRPM pipe ID 30 in.
Orlando, FL	2006	80 ft	CCFRPM pipe ID 72 in.
Norristown, PA	2006	112 ft	CCFRPM pipe ID 72 in.
Pasadena, TX	2005	3,945 ft	CCFRPM pipe ID 18 in.
Pasadena, TX	2005	1,701 ft	CCFRPM pipe ID 24 in.
San Antonio, TX	2005	2,666 ft	CCFRPM pipe ID 42 in.
Houston, TX	2005	31 ft	CCFRPM pipe ID 42 in.
Boston, MA	2005	292 ft	CCFRPM pipe ID 96 in.

8. ADVANTAGES AND LIMITATIONS

The main advantages of sliplining are simple installation, the ability to rehabilitate practically any pipe size, the variety of sliplining pipes on the market, and no need for flow bypassing in most cases. Thus, sliplining often offers an economical rehabilitation option for culverts. The method is capable of accommodating large radius bends. The method does not involve chemical processes and may be environmentally safe relative to other procedures (there is no Styrene, disposal off potentially contaminated process waters).

The main limitations of sliplining are the need for excavation of pits (although with shorter culvert lengths, digging of access pits may be avoided), and the grouting of the annular space (which is generally required). Other limitations often quoted are the reduction in flow cross-sectional area (although flow capacity could be recovered, or even increased, due to smooth interior surface of slipliner pipe) and the need for a sufficient work area (this can be significant). Numerous joints can be created with segmental sliplining, whereas with continuous sliplining the number of joints can be limited to only few.

9. REFERENCES

Ballinger, C.A., and P.G. Drake, 1995. ***Culvert Repair Practices Manual*** , Vol 1 & Vol 2 (Appendices), FHWA-RD-95-089, May 1995, US Department of Transportation, Federal Highway Administration (FHWA), McLean, VA, 330p & 321p

Caltrans, 2003. *Caltrans Supplement to FHWA Culvert Repair Practices Manual*, Design Information Bulletin (DIB) No. 83-01, June 2003, 136p.

CONTECH, 2002. "Corrugated Metal Pipe Arch Liner Project," case histories on web, http://www.contech-cpi.com/drainage/drainage_applications/rehabilitation/corrugated_metal_pipe/195, accessed on 09/18/08, CONTECH Construction Products Inc, West Chester, OH, 1p.

CONTECH, 2009a. *Aluminized Steel Type 2 Ultra Flo Liner (Case History*), case histories on web, http://www.contech-cpi.com/assets/viewer/view/913, accessed on 09/18/09, Contech Construction Products, West Chester, OH, 1p

CONTECH, 2009b. *Rehabilitating Aging Structures*, brochure, bro-rehab-3 3M 3/09 MC, http://www.contech-cpi.com/assets/viewer/view/5499, accessed on 07/07/09, 12p, CONTECH Construction Products Inc, West Chester, OH

CONTECH, 2009c. *Tunnel Liner Plate*, brochure, http://www.contech-cpi.com/media/assets/asset/file_name/1172/ESS_TunnelLinerPlate.pdf, accessed on 07/07/09, 20p, CONTECH Construction Products Inc, West Chester, OH

D. A. Van Dam & Associates, 2005. *The Pipe Liner*, Issue 1, Spring 2005, D. A. Van Dam & Associates, Hubbard, OH

D. A. Van Dam & Associates, 2006. *The Pipe Liner*, Issue 2, Spring 2006, D. A. Van Dam & Associates

D. A. Van Dam & Associates, 2008. *Large Diameter Pipe Projects*, case histories on web, http://www.kwhpipe.ca/case_drain.asp http://www.davandam.com/sys-tmpl/weholiteprojects, accessed on 12/10/08, D. A. Van Dam & Associates, Hubbard, OH

Duncan, C R, 1984. "Innovated Repair of a Large Failing Structural Steel Plate Pipe Arch Culvert," *Transportation Research Record 1001, Symposium on Durability of Culverts and Storm Drains*, pp.98-101

Goodwin, J., D. Gellings, D. McMillan, Jr., G. Chow, H. Sarvi, and R. Stude, 1997. "Specifications That Ensure Sliplining Success," *Trenchless Pipeline Projects-Practical Applications*, Boston, MA, Jun 8-11, 1997, Lynn E. Osborn, (editor), Pipeline Division, ASCE, pp. 390-397

Hobas Pipe USA, 2008. Hobas® Pipe USA, product information on web, http://www.hobaspipe.com/, accessed on 10/21/08, HOBAS Pipe USA, Houston, TX

INDOT, 2009. "725-R-541 Slip Lining of Existing Pipe," Standard specifications, Revised 01-04-08, 09-01-09, Indiana Department of Transportation (INDOT), 8p.

ISCO Industries, 2005. *Snap-Tite® Manual*, Version 2.0 2005, ISCO Industries, LLC, Louisville, KY, 75p.

Jenkins, C. F and A.E.Kroll, 1981 "*External Hydrostatic Loading Of Polyethylene Pipe*," */ASCE/* /Intl Conf. on Underground Plastics Pipe/, New Orleans, LA, Mar 30- Apr1, 1981, Jay Schrock, (editor), pp. 527-541.

Johnson, D. and J. Zollars, 1992. *Culvert Renewal*, Report No. MN/RO-92/02, April 1992, Mn/DOT, Maplewood, MN, 48p.

LINK-PIPE, 2008c. *Insta-Liner™ Installation*, company brochure, Link-Pipe Inc, Richmond Hill, ON, Canada, 8p

Kanters, D., 2007. "Government Agencies and Others Reduce Costs by Sliplining," *2007 Annual Conference of the Transportation of Canada*, Saskatoon, Saskatchewan, Canada, Oct 14-17, 2007, 8p.

Katti, D., K. Katti, and F. Yazdani, 2003. *Cost Effective Non-Flammable Pipe Liners*, prepared for North Dakota Department of Transportation (ND DOT), 52p.

KWH Pipe, 2008a. *Case Stories - Drainage & Roads*, case histories on web, http://www.kwhpipe.ca/in_English/Brochures_and_Case_Stories/Drainage_and_Roads, accessed 10/10/08, KWH Pipe, Mississauga, ON, Canada

KWH Pipe, 2008b. *Weholite® - A Culvert System*, product brochure on web, http://www.kwhpipe.ca/pdfs/Weholite_For_Culverts.pdf, accessed on 10/16/08, KWH Pipe, Mississauga, ON, Canada, 2p.

Phillips DriscoPipe, Inc, 1991. *Systems Design Manual*, Phillips Driscopipe Inc, Richardson, TX.

Phillips DriscoPipe Inc, 2002. *Polyethylene Piping Systems Manual*, First edition 1986, 71p.

Potter, A., 2009. “TerraBrute CR - The Missing Link in Your PVC System,” a presentation given at the Boston Municipal Users’ Forum, Boston, MA, Nov 10, 2009, 19 slides.

PPI, 1995. *Guidance and Recommendations on the Use of Polyethylene (PE) Pipe for the Sliplining of Sewers*, Guide 1/95, Plastic Pipe Institute, The Society of the Plastics Industry, Inc, Washington, DC, 16p.

Rinker Materials, 1992. *Concrete-Lined Corrugated Metal Pipe*, Info Series No 303, Jan 1992, 4p, technical information on web, http://www.rinkerpipe.com/TechnicalInformation/infoBriefs.shtml, accessed on 09/18/08, Rinker Materials, Houston, TX

Snap-Tite, 2008. *Culvert Rehabilitation Field Reports*, case histories on web, http://www.culvert-rehab.com/05_case_studies.php, accessed on 10/10/08, Snap-Tite, Louisville, KY

Stephens, P.J., 1996. "Project Guidelines for Slipline Grouting," *NO-DIG Engineering*, Vol.3, No.2, March & April 1996, pp.2-4.

Thornton, C.I., M.D. Robeson, L.G. Girard, B. A. Smith, 2005. *Culvert Pipe Liner Guide and Specifications*, FHWA-CFL/TD-05-003, Federal Highway Administration (FHWA), McLean, VA, July 2005, 169p

UNH T2, 2006. "On the Road in New Hampshire," *Road Business*, Winter 2006, Vol. 21 No. 4, University of New Hampshire (UNH) Technology Transfer Center (T2), Durham, NH, 2p.

Vaillancourt, G. 2002. “Inner Strength,” *Concrete Products*, Oct 1, 2002, Chicago, IL, 2p. http://concreteproducts.com/mag/concrete_inner_strength/

Zhao, J.Q., L. Daigle, and M. Willmets, 2003. "Controlling the Performance of Sliplined Pipe," *Infra 2003: The Changing Infrastructure Rehabilitation Market*, Montreal, Canada, Nov. 17-19, 2003, 10p.

Metal Culvert Overview Flowchart

Structural Defects Flowchart (Metal)

Bedding Deficiencies Flowchart (Metal)

Hydraulic Capacity Flowchart (Metal)